



HEAD OFFICE:
37 Paramount Blvd.
Derrimut Vic 3026
ABN: 70 095 343 123
Tel: 03 8390 6300 Fax: 03 8390 6366
EMAIL: ectglo@bigpond.net.au

Butlers sinks care and installation Guide

Material: Ceramic

Colour: White

Warranty: 10 Years (Product replacement only, not include the labour)

Waste size: 90mm

Waste(s) included: Yes

Waste(s) Type: Stainless Steel Basket Waste

Variance:

All ceramic sinks are handmade using traditional methods. They are 100% unique, slight variations in the finish from one sink to the other, which add a character to the sink. Dimensions may vary by up to plus or minus 3%. We recommend the customers do not cut out work surfaces or units until they have received their sink.

Installation Tip:

Any sealant used where the sink meets a bench-top needs to be flexible, rather than rigid to allow for any differential in expansion between the bench top and the sink.

When installing the waste fitting/s, it is important to use some silicone sealant between the stainless-steel waste flange and the glazed sink itself. This is to stop water from draining under the flange when the sink is filled. Please note that if surfaced are cleaned with a cloth dampened with Mineral Turps the silicone adheres very well. Also use the same cloth to clean up any excess silicone that squeezes out when the waste fitting is tightened. Ensure that the silicone is cleaned up before it dries.

Care and Maintenance:

Each ceramic sink is manufactured with a durable and non-porous finish. Your sink would be odour and stain resistant. Cleaning with a soft sponge and a non-abrasive product.

We recommend against using any undiluted chemical such as BLEACH.

Silvering may appear on surface, caused by metal pots and pans or cutlery. To remove it, we recommend using a fine car polish or cream cleanser. We suggest to put a stainless steel grid in the sink to prevent the damage by the pots and pans.